

NOMENCLATURE

B = Base	MDENTIL = Dentil Moulding	U = Utility
BC = Base Corner	MICW = Inside Corner	V = Valance
BEC = Base End Cabinet	MLR = Light Rail	VB = Vanity Base
BER = Base Easy Reach	MOCW = Outside Corner	VBL = Vanity Base Left Combo Unit
BFOOT = Bun Foot	MQR = Quarter Round	VBR = Vanity Base Right Combo Unit
BMW = Base Microwave Cabinet	MROPE = Rope Moulding	VDB = Vanity Drawer Base
BOXHOOD = Box Hood Starter Unit	MSW = Scribe	VDT = Vanity Drawer Tray
BP = Beaded Panel	MWC = Microwave Cabinet	VP = Veneer Panel
BWB = Base Waste Basket	OC = Oven Cabinet	VSB = Vanity Sink Base
BSKIN = Base Skin	ORG = Organizer	VSDB = Vanity Sink Drawer Base
BSPICE = Base Spice Pull Out (no filler)	P = Panel	W = Wall
CCROWN = Cove Crown	POS = Pull-Out Shelf	WC = Wall Corner
CORBEL = Corbel	PR = Plate Rack	WDC = Wall Diagonal Cabinet
DB = Drawer Base	REF = Refrigerator Panel	WEC = Wall End Cabinet
DD = Double Door	REVCROWN = Reversible Crown	WF = Wall Filler
DEP = Decorative End Panel	ROS = Rosette	WMC = Wall Medicine Cabinet
DWEP = Decorative Wall End Panel	RW = Refrigerator Wall	WMD = Wall Mullion Door (Door prepped for Glass)
DWP = Dishwasher End Panel	SB = Sink Base	WMDC = Wall Mullion Diagonal Cabinet (Door prepped for Glass)
F = Filler	SCB = Sink Corner Base	WSPICE = Base Spice Pull Out (no filler)
FB = Furniture Base	SCBFF = Sink Corner Base w/ Front & Floor	WR = Wine Rack
FF = Fluted Filler	SLGCROWN = Large Crown for Full Overlay	WSKIN = Wall Skin
FWF = Fluted Wall Filler	SMCROWN = Small Crown	B12 = Base 12" Wide
LEG = Leg	SS = Super Lazy Susan	W3030 = Wall 30" Wide, 30" High
LGCROWN = Large Crown	SSMCROWN = Small Crown for Full Overlay	
LS = Lazy Susan	STCROWN = 2-Pc. Starter Crown	
MBAT = Batten	TFOOT = Tapered Foot	

FINISH PROCESS

1. All surfaces are machine-sanded.
2. Dust particles are removed before entering each spray machine.
3. Product enters an automated finish system where solvent-based pigment stain is applied.
4. Product is sealed and put through a pre-cure drying process.
5. Complete cure is done with slow bake process.
6. All edges of parts are hand-sanded before being put in a brush-sanding machine.
7. Final topcoat is applied and put through a pre-cure process followed by slow bake for final, thorough curing.
8. Clear finishes use a catalyzed varnish, and paint finishes use a post-catalyzed lacquer.
9. Products are inspected for defects, cleanliness and smoothness.
10. The front side of the products gets a stain coat, a sealer coat and final top coat. The backs of drawer fronts and doors get a stain coat and a sealer coat.

MOULDING

	Cubes	Description
SMCROWN214	.125	2 1/4" Crown
SSMCROWN214	.25	2 1/4" Full-Overlay Crown Seated on top of cabinet with 3/8" top nailing flange
LGCROWN4	.25	4" Crown
SLGCROWN4	.25	4" Full-Overlay Crown Seated on top of cabinet with 3/8" top nailing flange
STCROWN	.25	4" Starter Crown; not finished on back
CCROWN134	.125	1 3/4" Cove Crown
REVCROWN ‡	.25	4-way adjustable cove and shaker combo
MLR	.083	Light Rail
MSW ‡	.083	Scribe
MBAT ‡	.083	Batten
MQR ‡	.083	Quarter Round
MICW ‡	.083	Inside Corner
MOCW ‡	.083	Outside Corner
MDENTIL ‡	.125	Dental Inlay
MROPE ‡	.125	Rope Inlay
FB	.25	4 1/2" Furniture Base
ROS3	.1	3" Rosette
TOEKICK ‡	.83	4 1/2" Toekick (Plywood w/vinyl veneer)
TOEKICKADA ‡	.83	9" Toekick (Available as KAT single 8' pc)

- Available in all colors
- ‡ = Heritage Brown will not have visible decorative glazing. For Crimson Glaze, order standard Crimson.
- Drawings not to scale. Please use dimensions shown.
- Moulding sold as single 8 foot piece
- ROS3 sold as each

